





















	Step 1	Step 2	Step 3	ansamblu final
				
Imbinare panee <i>Panel Installation</i>				
Metoda de asamblare exclusiva, patentata la nivel mondial <i>World Exclusive Printed Matching Trims Patent Pending</i>				
Montare coltar interior <i>Inside Corner Trim Installation</i>				
Montare element de imbinare <i>Joining ('H') Trim Installation</i>				
Montare element de start / inchidere <i>Start & End ('J') Trim Installation</i>	